



FIBERTECH DOOR SYSTEM

Tent Door Assembly Instructions

1. Insert Pc (K) into either Header Tube and secure with Pc (B) with Washer (Finger Tight).
2. Slide opposite Side Frame Pc over Pc (K) and secure with Pc (B) with Washer (Finger Tight).
3. Drop Pc (J) over the top of header Tubes and align with Holes. Secure with Pc (A) Bolt & Washer. All Bolts may now be tightened being careful not to collapse tubes.
4. Install frame where desired being careful to maintain equal distance top and bottom between jamb sections. For Tent with no Eave Tube, Extrusion Arms can install horizontally in Header, Attach to tent frame using Extension Arms (E) and Top Brackets.
5. Install doors and attach closer arms.

NOTE: Proper operation of the doors may require shimming under the base plates to obtain a true vertical jamb alignment.

Double Door Crate Contents

Sidewall Door Opening 6'1"(w) X 6'9"(h)

FRAME PARTS:

- C. Left Side "L" Shaped Leg1
- D. Right Side "L" Shaped Leg1
- E. Extension Tube.....2
- F. Door Closer with Arm.....2
- G. Left Swing Door1
- H. Right Swing Door1
- J. 6' Header.....1

TOOLBOX:

- Tool Box.....1
- K. 8" White Channel.....1
- Top bracket for extension tube2
- 5/16" Nylon Nut and Washer (Closer Arm)....2
- R. 3" Carriage Bolts for Top Bracket.....2
- A. 3/8" X 2-3/4" Bolts6
- B. 3/8" X 3/4" Bolts for 8" Channel.....2
- N. 3/8" Nylock Nuts4
- 3/8" Flat Washers for Bolts in Header6
- M. 1/4" X 1/2" Thumb Screws.....4
- Combination Box/Ratchet Wrench.....1
- Fibertech Brochure.....1
- Door Closer Instructions1
- Extra Hardware Bag.....1
- Packing List.....1

